

## EXPANSION VALVES

	DESCRIPTION	INLET	OUTLET	CAPILLARY LENGTH	EQUALIZER LENGTH NUT	DTAC NO.
	Internal Equalizer	#6 MF	#8 MF	12"		<b>04-15001</b>
	Internal Equalizer	#6 MO	#8 MO	12"		<b>04-15001-0</b>
	External Equalizer	#6 MF	#8 MF	18"	18", 1/4" FF	<b>04-15002</b>
	External Equalizer	#6 MO	#8 MO	13"	13", 1/4" FO	<b>04-15003</b>
	External Equalizer	#6 MO	#8 MO	33"	33", 1/4" MO	<b>04-15005</b>
	External Equalizer	#6 MO	#8 MO	8"	8", 1/4" MO	<b>04-15007</b>
	Internal Equalizer Peterbilt	18MM	20MM	14"		<b>04-15010</b>
	Internal Equalizer Peterbilt	16MM	20MM	14"		<b>04-15011</b>

## EXPANSION VALVES BLOCK TYPE

<p>No. 10</p> <p>No. 6</p> <p>No. 8</p> <p>No. 8</p>	<p>#6 FO</p> <p>#10 FO</p>	<p>DTAC NO.</p> <p><b>04-15004</b></p>
<p>No. 10</p> <p>No. 8</p> <p>No. 10</p> <p>No. 6</p>	<p>#6 FO</p> <p>#8 FO</p>	<p><b>04-15004-1</b></p>
<p>Block Exp. Valve IHC</p>		<p><b>04-15006</b></p>
<p>Block Exp. Valve IHC</p>	<p>#6 FO Flange Mount</p> <p>#10 FO Flange Mount</p>	<p><b>04-15008</b></p>
<p>No. 10</p> <p>No. 6</p> <p>No. 8</p> <p>No. 8</p>	<p>#6 FO</p> <p>#10 FO</p>	<p><b>04-15009</b></p>
<p>No. 8</p> <p>No. 8</p> <p>No. 10</p> <p>No. 6</p>	<p>#6 FO Flange Mount</p> <p>#10 FO Flange Mount</p>	<p><b>04-15018</b></p>

## EXPANSION TUBES

	<p><b>DESCRIPTION</b></p> <p>Expansion Tube Repair Kit</p>	<p><b>DTAC NO.</b></p> <p><b>04-15013</b></p>
	<p>Expansion Tube GM - White</p>	<p><b>04-15014</b></p>
	<p>Expansion Tube Ford - Blue</p>	<p><b>04-15015</b></p>
	<p>Expansion Tube Peterbilt Red</p>	<p><b>04-15025</b></p>
	<p>Purple - Navistar</p>	<p><b>04-15070</b></p>
	<p>Expansion Tube CAT Black &amp; White</p>	<p><b>04-15075</b></p>